Fuga-Wash Eco Code: P878 2018/08-UK

Fuga-Wash Eco

Eco-friendly detergent to be used as an additive in water used to clean Fugalite® Eco, Fugalite® Eco Invisibile, Fugalite® Bio and Fugalite® Bio Parquet, ideal for use in GreenBuilding. Water-based concentrate, solvent-free, safeguards the health of both operators and the environment.

Fuga-Wash Eco, when used as an additive in cleaning water, has a specific detergent action that does not damage ceramic tile, porcelain tile and natural stone surfaces.









PRODUCT STRENGTHS

- · Facilitates cleaning of covering materials
- · Keeps the sponge cleaner
- · Cleans thoroughly, no need to rinse
- Improves the surface finish of the grout
- Suitable for all surfaces

AREAS OF USE

Use

To be added to the cleaning water for Fugalite® Eco, Fugalite® Eco Invisibile, Fugalite® Bio and Fugalite® Bio Parquet.

Substrates:

- ceramic, porcelain tiles
- glass mosaic, marble and natural stone

Do not use

To remove residues and streaks of hardened grout.

INSTRUCTIONS FOR USE

Preparation of substrates

The coating materials must first be cleaned to remove any dust. Fugalite® Eco, Fugalite® Eco Invisibile, Fugalite® Bio and Fugalite® Bio Parquet must still be fresh.

Preparation

Fuga-Wash Eco is a ready-to-use transparent fluid that can be diluted with water in any ratio. Shake the bottle well before opening in order to redisperse the liquid evenly. Pour one measuring cap (approx. 50 ml) for every 5 litres of water in the cleaning tray.

Application

Begin cleaning the tilework when the grout is still fresh. On completion, pour Fuga-Wash Eco into the cleaning tray in the quantities indicated, then clean up the surface using a thick, large-sized damp sponge, preferably made of cellulose, to avoid removing grout from the joints. Use circular movements to soften the film of grout on the tiles and finish cleaning the joint surface. Specific high-dispersion polymers ensure all grout residues are removed using only a small amount of water. The use of an excessive amount of water when cleaning would impair the final chemical resistances. Rinse frequently and make sure clean water is used at all times, using appropriate trays and grills with cleaning rollers. If necessary, replace the sponge or felt cleaning pad when saturated with grout. Final cleaning should be done, by sponge applied in a diagonal directions to avoid material coming out from the joints. Wipe the cleaned surface again with a dry cloth to make sure it is completely clean and there are no streaks of resin remaining.

Cleaning

Residues of Fuga-Wash Eco can be cleaned from tools by rinsing them thoroughly.



Appearance	Transparent liquid
Specific weight	≈ 1 kg/dm³
Shelf life	≈ 24 months in the original packaging
Warning	Protect from frost, avoid direct exposure to sunlight and sources of heat
Pack	bottles 1.5 ℓ
Water dilution ratios	All ratios
	recommended dosage 1 measuring cap every 5 ℓ of water in the washing tray
рН	≈7
Temperature range for application	from +5 °C to +35 °C
Coverage	≈ 100 – 200 m²/1 ℓ

WARNING

- Product for professional use

- abide by any standards and national regulations
- store and use at a temperature above +5 °C. Protect from frost
- do not leave cans or bottles open, even during use
- if necessary, ask for the safety data sheet
- $for any other issues, contact the Kerakoll Worldwide \ Global \ Service \ 01527 \ 578000 in fo@kerakoll.co.uk$

The Eco and Bio classifications refer to the GreenBuilding Rating® Manual 2012. This information was last updated in September 2018 (ref. GBR Data Report - 08.18); please note that additions and/or amendments may be made over time by KERAKOLL SpA, for the latest version, see www.kerakoll.com. KERAKOLL SpA, shall therefore be liable for the validity, accuracy and updating of information provided only when taken directly from its institutional website. The technical data sheet given here is based on our technical and not practical knowledge. As it is not possible for us to directly check the conditions in your building yards and the execution of the work, this information represents general indications that do not bind Kerakoll in any way. Therefore, it is advisable to perform a preliminary test to verify the suitability of the product for your purposes.

