



UltraCare Keramet Easy

Ready to use acid spray cleaning product that also removes cementitious residues immediately after grouting. Removes surface residues of cement, lime and efflorescence. Suitable for cleaning the back side of porcelain tiles

DESCRIPTION

UltraCare Keramet Easy is used for cleaning internal and external surfaces that have been grouted using cementitious grouts and can be used on all acid resistant materials, such as porcelain, ceramic, glass mosaics, quarry tiles, terracotta and acid-resistant natural stone.

FEATURES AND BENEFITS

UltraCare Keramet Easy is a simple and ready to use product to save time as it can be used also immediately after grouting. It is suitable for use on porcelain, ceramic, glass mosaics, quarry tiles, terracotta and acid-resistant natural stone. When installing large-format tiles, it is perfect for removing fresh cementitious grout residues to avoid the "frame effect". It is also suitable for cleaning the back side of tiles prior to installation, especially with large formats.

PRODUCT INFORMATION

UltraCare Keramet Easy is a liquid acid cleaner available in 3% aqueous solution; the product is ready to use and does not require any dilution.

UltraCare Keramet Easy is based on a special organic acid, whose advantage is to have an aggressiveness towards cement grout residues and efflorescence's, equal to that of much stronger acids (muriatic/chloridian, sulfuric, etc.), without developing, like the latter, very dangerous toxic fumes. In any case, using the product in well-ventilated areas is recommended.

UltraCare Keramet Easy when properly used, will not damage the grout joint even when using coloured grouts.

APPLICATION METHOD

When used immediately after cementitious grouts, wait until it loses its plasticity and becomes opaque (the time required depends on the type of grouting product used), then spray **UltraCare Keramet Easy** evenly on the surface to be cleaned, leave it to react for 1-2 minutes and then proceed with a first cleaning using a moist cellulose sponge (MAPEI sponge type), working diagonally over the grout joints. Rinse the sponge frequently using two different containers of water, one to remove the excess grout from the sponge and the other for rinsing the sponge.

On light cured grout residues spray **UltraCare Keramet Easy** evenly over the entire area at a suitable distance, working in manageable areas, letting it act for a few minutes. Then wipe over the surface removing it with the use of a moist cellulose sponge as described above.

UltraCare Keramet Easy may also be used on cured grouts with light residues, otherwise use **UltraCare Keramet** in compliance with the indications of the specific technical data sheet.

CAUTIONS

- Never use **UltraCare Keramet Easy** on marble or calcareous stone.
- Do not use **UltraCare Keramet Easy** on ceramic tiles or enameled baths with non-acid-resistant enamel.
- Use **UltraCare Keramet Easy** with rubber gloves and glasses, paying attention to splashes on the skin or clothes.

UltraCare Keranes Easy



TECHNICAL DATA (typical values)

PRODUCT IDENTITY

Consistency:	liquid
Colour:	transparent
Density:	1.00 g/cm ³
pH:	1.4
Application temperature range:	0°C to +40°C
Waiting time before rinsing:	5 minutes

- Make sure before use that the surfaces to be cleaned are acid-resistant. It is advisable, in doubtful cases, to carry out preliminary tests.
- Do not allow **UltraCare Keranes Easy** to react for too long and rinse thoroughly to remove all traces of the product; it could discolour the grout.
- **UltraCare Keranes Easy** does not damage metal or galvanized surfaces; however, given the variety of materials available on the market, a preliminary test is always recommended.

CONSUMPTION

Depending on the needs, it can vary based on the degree and type of dirt and the surface to be treated.

PACKAGING

UltraCare Keranes Easy is available in 750 ml bottles with spray.

SHELF LIFE

UltraCare Keranes Easy, stored in the original packaging, has a storage time of 24 months.

SAFETY INSTRUCTIONS FOR PREPARATION AND APPLICATION

Instructions for the safe use of our products can be found on the latest version of the Safety Data Sheet, available from our website www.mapei.com.

PRODUCT FOR PROFESSIONAL USE.

WARNING

Although the technical details and

recommendations contained in this product data sheet correspond to the best of our knowledge and experience, all the above information must, in every case, be taken as merely indicative and subject to confirmation after long-term practical application; for this reason, anyone who intends to use the product must ensure beforehand that it is suitable for the envisaged application. In every case, the user alone is fully responsible for any consequences deriving from the use of the product.

Please refer to the current version of the Technical Data Sheet, available from our website www.mapei.com

LEGAL NOTICE

The contents of this Technical Data Sheet ("TDS") may be copied into another project-related document, but the resulting document shall not supplement or replace requirements per the TDS in force at the time of the MAPEI product installation.

The most up-to-date TDS can be downloaded from our website www.mapei.com.

ANY ALTERATION TO THE WORDING OR REQUIREMENTS CONTAINED OR DERIVED FROM THIS TDS EXCLUDES THE RESPONSIBILITY OF MAPEI.

All relevant references for the product are available upon request and from www.mapei.com



BUILDING THE FUTURE